

DeviceLab Payload Collector, - Getting started!

Find and download your installation file on the DeviceLab website... https://devicelab.dk/



Locate your downloaded installation file and double-click to start the installation.





Press "Next" to accept setup...



Press "Next" to accept Licence agreement...





Press	s "Ne	ext" to a	ccept	or e	dit ins	tallatio	n locatio	n			
🕹 🗟 📙 🖛	Downloads									-	0 X
File Home	e Share	View									^ ?
Pin to Quick Cop access	py Paste	Cut Copy path Paste shortcut Copy path Paste shortcut	Delete Renar Organize	ne New folder New	ew item * Isy access * Properti V	Edit Gpen → Fdit	ct all ct none rt selection elect				
← → • ↑	🔪 🦊 > This P	C > Downloads							Search Downloads		
 ✓ Quick acc Desttop Docume Docume Pictures Videos Videos This PC Desttop Docume Docume Docume Quintures Videos Videos Videos Videos Videos Videos Videos Videos Wint0_c 	scess , * ads * ents ents ads SC (C.)	Name ~ Today (1) f ² PayloadCollector-Inst	aller-0.2.12.52-Relea	sse-x64.msi	Date modified	Type ector App (64 bit) Setup Folder Install to the default folder of I Collector App (64 bit) to: Ies/DeviceLab/Collector App		C A			
	ILS (D:)						Pade Novt	Concel			
🚅 Network							USA TEAL	Laite			
1 item											1
🚛 🔎 ग्	ype here to s	search	<i>•</i> 🔁	O	U	🤁 👘				へ 臣 (4) 08:57 28-06-2	024 🖵

Press "Install" to start installation...

🔷 🛛 🗹 📑 🗘 I Downloads	
File Home Share View	^ ?
Pinte Quick Copy Paste Brotrout Detet Rename Pinte View Iden Pinte Specifies Pinter Specifies	
ulipuolai ongainze new Open seeu	
 → ↑ ↓ Thic PC → Downloads Out a scess Out a scess Determodified Determodif	
litem	III 🖬
📰 🖉 Type here to search 🛛 🙍 💽 📑 📭 🙆 🚹 🐺	08:58
	28010021124 ×



Depending on the Windows security setup, a "User Account Control" might popup... – press "Yes"



Press "Finish" to complete the installation...





Select "Windows Start", find the "DeviceLab" folder and press "Payload Collector App (64bit)" to activate program start!



Copy your "Machine code" and mail it to "info@devicelab.dk" to get your license key and press "Enter License".





Enter your received license key and press "Validate license".

🖊 👱 📙 🖛 Downloads		
File Home Share View		^ (?)
Pin to Quick. Corpy Paste shortcut. Pin to Quick. Corpy Pin to Quick. Corpy	Bopen - Belect all Fetters Faith + Seek drame Seek drame Copen - Seek -	
← → ▼ ↑ ↓ → This PC → Downloads		
Quickacces Name Date modif Outcone Viday (1)	řed Type Sze	
Downloads # 18 PayloadCollector-Installer-0.2.12.52-Release-x64.msi 28-06-2024	08:51 Windows Installer 62.068 KB	
Documents	– 🗆 🗙	
Pictures *	when the linear and a second from Deviced at when a surface to the Device of Collector Aca	
Music trial left.	nter the license code you were issued from DeviceLab when purchasing the Payload Collector App	
📱 Videos	٨	
This PC	4)	
Desktop		
Documents		
Upper Downloads		
h Music		
Pictures		
🛒 Videos		
📥 Win10_OS (C:)		
HP_TOOLS (D:)	Validate license Cancel	
Retwork		
		1011
🗄 🔎 Type here to search 🛛 🖉 💽 🌍 拱 🦪		~ 臣 4 ⁽¹⁾ 28-06-2024

Enter a "Master password" of your own to the "Payload Collector" keystore. Note! – that forgotten password can't be restored!

💙 🛛 🚽 🚽 🖓 🐨 🖓 🐨 🖓 Downloads		
File Home Share	View	^ ?
Pin to Quick Copy Paste access	Cot More Copy path Easy access + For Copy path <	
\leftarrow \rightarrow \checkmark \uparrow \downarrow \rightarrow This	is PC > Downloads - くろ Search Downloads	
★ Quick access ■ Desktop	Name Date modified Type Size	
Downloads 3	👷 🧬 PayloadCollector-Installer-0.2.12.52-Release-x64.msi 28-06-2024 08:51 Windows Installer 62.068 KB	
Documents 3	<i>x</i>	
Fictures 🤉	🖈 😵 Enter master passphrase for keystore – 🗆 🗙	
👌 Music	Enter master password for key store. This password cannot be recovered. So the only	
🚦 Videos	solution to a forgotten password is to reset the keystore and start from scratch	
💻 This PC		
🧮 Desktop	Password:	
Documents		
Downloads		
Music	Repeat:	
Videos		
Win10 OS (C)	OK Cancel Reset keystore	
HP_TOOLS (D:)		
THE HEINOR		
1 item		
		10:16
Type here to		28-06-2024



Depending on your hardware, you will need to find and install drivers...



For your "Compact Payload Collector":

Find the driver here... <u>https://www.silabs.com/developers/usb-to-uart-bridge-vcp-</u> <u>drivers?tab=downloads</u>

For your "Extended Range Payload Collector":

Find the driver here... https://ftdichip.com/drivers/d2xx-drivers/

- and the corresponding installation guide here... https://ftdichip.com/document/installation-guides/



Identify the COM port for your Payload Collector hardware device... Connect the device and select:



Select "Frames" and "Open serial port" and you're good to go!!!

File Home	Share View													^ (2)	
No No Corp ofth No															
< > ×	E to This Do File B	dit Keyr	nanagement Remote	e Rep	ports										
Open serial port Close serial port Serial port Serial port Serial port Close se															
	Frames	Matara	Catur									-			
Curck access			need of the second											~	
Desktop	x* Kecept	ion time	RSSI Senal Manufac	turer	Version Device Desci	ription Stat	us Deco	ded Main value Field count Repeated Enc	ryption	mode Err	or flags Parse errors	Error	lags		
Downloads 🖈 Fields															
Documents #											Description Mahas Liket Sublight Tariff Starson				
🚍 Petures 📲 🛛 🔤 🕫 🖓 Downloads —C3 🛛 ×															
🔥 Music	File Home St	hare N	new											^ (
# Videos	🖈 🖣 🛙	<mark>∦</mark> α ∞ α	it 😽 🛃	1	🗙 🛋	📕 🕌	ewitem · syacces	r 📝 🙀 Open * 👬 Select all							
This PC F	An to Quick Copy Pas access	¹⁰ 🖬 🕫	ste shortrut Move	Copy	Delete Rename	New		Properties History	ion						
Desktop			S DeviceLab Collec	ctor Ap	p v. 0.2.12.52+df6b5961	1 cef906fed51	7ef475f3	42667d3b1b36a - Licensed to Karsten						- 🗆 🗙	
Documer	<u>د</u>	This BC	File Edit Key man	nagemi	ent Remote Reports	5								0	
👃 Downloa			Open serial port	Clos	e serial port 👘 Sea	rch		Decoded Required	Frames	captured:	54 Total meters: 54	(0 Four	d 0 Mia	sing)	
Music			Frames Meters Se	etun											
Pictures	Quick access		0	l or ce	Could Mandata		Derive	Durrichies	Care 11	Deceded	Mala calue - Field accus	0		fundam A	
III Materia	Desktop		Neception time	100	Serial Manufactu	ner version	Device	Description	368105	Decoded	Main value Field count	Repeate	o en	Error mags	
Videos	🕹 Downloads		28.06.2024 11.40.05	-99	06596901 KAM	10	04	MultiCal 601 - Meat meter unlume at return		H	1	H	01/0	Fields	
winto_0.	Documents		28.06.2024 11.40.05	.03	69074428 KAM	10	04	MultiCal 602 - Heat meter, volume at return		<u> </u>	1	1	FIL	Description Value Unit SubUnit Tariff St	
HP_TOOL	E Pictures		28.06.2024 11.40.05	-102	65017383 KAM	14	0C	MultiCal 601 - Heat meter, volume at flow			1		EIL	On time 5387499 minutes 0 0 0	
Network	Music		28.06.2024 11.40.04	-96	06839592 KAM	1A	04	MultiCal 601 - Heat meter, volume at return			1	1	EIL	< >	
-	I Videos		28.06.2024 11.40.04	-104	69403132 KAM	10	04	MultiCal 602 - Heat meter, volume at return			1		EII	Legend: Main Due date Error field	
			28.06.2024 11.40.04	-99	80024093 KAM	35	0C	MultiCal 603 - Heat meter, volume at flow			1		EII	Hexadecimal encoded wireless frame	
	💻 This PC		28.06.2024 11.40.03	-103	06699758 KAM	1A	04	MultiCal 601 - Heat meter, volume at return			1	<u> </u>	EII	7A 44 2D 2C 51 30 40 69 1C 04 8D 20 1F	
	E Desktop		28.06.2024 11.40.03	-04	73000130 NAM	14	32	Unidirectional repeater		141 1	13	1	- Un	25 14 5D 5A 94 2B 9F 43 F9 D9 04 2D BA	
	Documents		28.06.2024 11.40.02	.08	73004257 KAM	04	32	Unificational reneater		H	1	H	-	9D 3C 81 9C 70 97 1E 85 19 3D 3C CF A7	
	Downloads		28.06.2024 11.40.02	-100	06339392 KAM	14	04	MultiCal 601 - Heat meter, volume at return			1		Elle	82 67 72 D4 6D 06 DB 7C 0E E8 94 16 6E 49 51 8D 9D 3B 76 97 F2 48 B3 B6 22 6C	
	Music		28.06.2024 11.40.02	-104	23702170 KAW	3C	16	KWMxxxx series - Cold water meter			1		Elle	9A 22 AE 29 64 3F 3B A9 AC 8F FB D9 34	
	Dictore		28.06.2024 11.40.02	-53	00004797 KAM	FE	02	Electricity meter	63		1		Mc	10 E5 D5 99 B4 95 7E 29 D4 BF FF A2 03	
			28.06.2024 11.40.02	-99	76778310 KAM	18	16	MultiCal 21 - Cold water meter			1		EII		
	Videos		28.06.2024 11.40.01	-88	23016815 KAW	3A	16	KWM2210 - Cold water meter			1		EII		
	Win10_OS (C:)		28.06.2024 11.40.01	-105	69190447 KAM	10	04	MultiCal 602 - Heat meter, volume at return			1	4	EIL		
3 items 1 iten	HP_TOOLS (0:)		28.06.2024 11.40.01	-102	07124685 KAM	14	04	Nwntoox series - Loid water meter MultiCal 601 - Heat meter unlight at online					Ell		
💶 . О ту	Network		28.06.2024 11.40.01	-45	10229500 TCH	64	0.0	Heat cort allocator	00	H	1	- m	M		
			28.06.2024 11.40.01	-106	23161580 KAW	34	16	KWM2210 - Cold water meter	00		1	ă	Elle		
			28.06.2024 11.40.01	-98	06561029 KAM	1A	04	MultiCal 601 - Heat meter, volume at return			1	1	EIL		
			28.06.2024 11.40.01	-101	73004262 KAM	04	32	Unidirectional repeater			1				
			28.06.2024 11.40.00	-104	06555936 KAM	14	04	MultiCal 601 - Heat meter, volume at return			1		Ell		
			28.06.2024 11.40.00	-88	73004254 KAM	04	32	Unidirectional repeater			1		+		
			28.06.2024 11.40.00	-97	69190412 KAM	10	04	MultiCal 602 - Heat meter, volume at return			1		Elle		
			28.06.2024 11.40.00	-105	25021515 KAW	SA BC	10	KWM2210 - Cold water meter					Elle V		
			<										>	× .	
			Unsaved changes											MQTT: False	